

FLEX
AREA

The floor plan shows a compact living space. At the top left is a 'FLEX AREA'. Below it is a 'KITCHEN' containing a sink, a four-burner stove, and a refrigerator. To the right of the kitchen is a 'BATH' with a toilet, a sink, and a bathtub. Above the bathtub is a 'W/D' (washer/dryer) unit. At the bottom left is an 'F/P' (front porch) with a door. At the bottom right is a 'MURPHY BED' area, indicated by a dashed line. The entire space is enclosed by a thick black border representing the walls.

KITCHEN

W/D

BATH

F/P

MURPHY
BED